INSTALLATION INSTRUCTIONS

WALL PASS THRU UNITS - BOTTOM HOLD



9800 Mount Pyramid Court Fourth Floor Englewood, CO 80112

INSTALLATION

INSTRUCTIONS

DVWM00<u>62SH</u>

Tools and Materials that may be required:

- 4, 10/32 Screws (provided).
- Phillips head screw driver
- Other tools/materials may also be necessary depending upon actual installation

Installation Procedure:

1. <u>Determine the location of the Top Pass Thru-Wall Vault unit.</u> The Top Vault is dVault Product Number DVWM0062S and is sold separately.

<u>General Installation</u>: Wall Pass Thru units may be installed in finished or unfinished walls (such as a garage wall). IMPORTANT NOTE: If installation is intended for a finished wall, it is very important to consult with licensed professionals. Finished walls may conceal electrical, plumbing or other elements that may be hazardous requiring licensed professional installation.

Other installations such as pillars or gated entryways may require a mason or ironworker. Always consult with a professional prior to installing your wall pass thru unit.

- 2. Install optional package drop hold with four Phillips head machine screws (4, 10/32" X 1/2"). Open the key-locked access door to gain access and see assembly holes. Align the bottom hold with the pem nut holes in the Top Vault. Install all four screws and tighten as needed (Caution: Do not over tighten screws).
- 3. Check installation for airways and gaps that may require insulation, flashing, sealing and/or trim work.

NOTE: Do not veneer security-drop door or alter the weight of the door mechanisms in any way. Doing so may cause the door mechanisms to malfunction.

IT IS IMPORTANT TO CONSULT WITH LICENSED PROFESSIONALS WHEN INSTALLING WALL-MOUNT UNITS IN EXISTING OR FINISHED WALLS. <u>WARNING: FINISHED WALLS MAY CONCEAL ELECTRICAL WIRING, PLUMBING AND/OR OTHER HAZARDOUS ELEMENTS.</u>

(installation diagram on the back)

